



CATÁLOGO DE PARTES



VICTORY




SISTEMA DE
ENCENDIDO
AUTOMÁTICO
DE LUCES

Para mayor información del
sistema consulte página
[web](https://www.auteco.com.co/) <https://www.auteco.com.co/>
sistemas-de-seguridad/ah



SISTEMA
ANTIBLOQUEO
DE FRENO
NO INCLUIDO



LUCES DE
CIRCULACIÓN
DIURNA
NO INCLUIDAS

Mobil Super
4T Ultra

www.auteco.com.co | servicioalcliente@auteco.com.co
Línea gratuita nacional: 018000 520090 | [f](#) [t](#) [v](#)



CON EL RESPALDO





PREFACIO

Es nuestro placer presentarles a ustedes el Catálogo de Partes.

Este Catálogo ha sido especialmente diseñado para ayudarle en la selección de las partes correctas con el fin de mantener el vehículo en las mejores condiciones.

Los repuestos originales están sujetos a un exigente estándar de control de calidad, por lo tanto es necesario que usted sólo use repuestos originales.

En nuestro constante esfuerzo para mejorar la eficiencia y desempeño de su vehículo, las especificaciones, diagramas y número de partes pueden cambiar sin previo aviso. Consecuentemente las descripciones de los repuestos en este Catálogo pueden no ser las finales y definitivas.

Las alteraciones y modificaciones que ocurren en la impresión de este Catálogo, serán informadas a nuestra red, a través de circulares de Servicio o en nuestra página web: www.auteco.com.co accediendo al link repuestos. Es requisito que usted actualice su Catálogo y haga las correcciones necesarias, una vez reciba dichas circulares. Lo anterior le asegurará un rápido y adecuado despacho de sus partes, pues las órdenes están siendo diligenciadas con las referencias más actualizadas.

En caso de necesitar asistencia técnica, comunicarse con el Distribuidor Autorizado o llamar al Departamento de Servicios Auteco.



DIRECTORIO TELEFÓNICO - UN REPUESTOS Y ACCESORIOS ÁREA COMERCIAL Y ASESORES DE VENTAS

NOMBRE	CARGO	ZONA	CELULAR	CORREO ELECTRÓNICO
Anderson Gonzales Barrios	ASESOR COMERCIAL	Ibagué - Dorada	320 682 09 82	agonzalez@autecomobility.com
Astrid Johana Cruz Silva	ASESOR COMERCIAL	Granada - Acacias	318 617 26 92	acruz@autecomobility.com
Biviana Andrea Martinez Gañan	ASESOR COMERCIAL	Barranquilla - Soledad	314 701 17 85	bmartinez@autecomobility.com
Carlos Mauricio Garcia Chaparro	ASESOR COMERCIAL	Bogota Centro	300 346 14 86	cgarcia@autecomobility.com
Carolina Ruiz Montoya	ASESOR COMERCIAL	Cartagena	313 584 72 62	cruiz@autecomobility.com
Claudia Patricia Ramirez	ASESOR COMERCIAL	Bogota	301 247 71 10	cpramirez@autecomobility.com
Cristian Arlevis Muñoz Soto	ASESOR COMERCIAL	Oriente - Nordeste	318 614 02 70	camunoz@autecomobility.com
Cristian David Cantillo Baena	ASESOR COMERCIAL	Quibdó	317 481 39 43	ccantillo@autecomobility.com
Daniel Mauricio Hernandez Rendon	ASESOR COMERCIAL	Pereira	301 375 43 57	dmhernandez@autecomobility.com
Darwin Arley Navarro Quintero	ASESOR COMERCIAL	Cúcuta	318 614 28 51	dnavarro@autecomobility.com
David Antonio Lazaro Lopez	ASESOR COMERCIAL	Aguachica	321 271 47 43	dlazaro@autecomobility.com
Diego Fernando Acevedo Rincon	ASESOR COMERCIAL	Villavicencio	314 891 29 54	dfacevedo@autecomobility.com
Diego Mauricio Gomez Ardila	ASESOR COMERCIAL	Armenia - Cartago	317 481 40 80	dgomez@autecomobility.com
Efraín Eliceo Guerrero Sanchez	ASESOR COMERCIAL	Área Metropolitana Norte	301 375 25 32	eguerrero@autecomobility.com
Giovany Montoya Alzate	ASESOR COMERCIAL	Poblaciones Suroeste	314 786 55 44	gmontoya@autecomobility.com
Hackerman Jose Agamez Duque	ASESOR COMERCIAL	Sincelejo - Magangué	321 701 19 03	hagamez@autecomobility.com
Hernan Alonso Pedraza Garcia	ASESOR COMERCIAL	Bogota Sur - Fusagasugá - Soacha	314 812 64 53	hpedraza@autecomobility.com
Jaime Alberto Orozco Jimenez	ASESOR COMERCIAL	Buga - Buenaventura	318 605 87 75	Jaorozco@autecomobility.com
Jesith Fernando Rodriguez	ASESOR COMERCIAL	Pasto	310 444 22 15	jfrodriguez@autecomobility.com
Jorge Eduardo Pinilla Torres	ASESOR COMERCIAL	Tunja - Sogamoso	310 407 40 72	jpinilla@autecomobility.com
Jorge Mario Gil Rios	ASESOR COMERCIAL	Área Metropolitana Sur	313 672 73 53	ggil@autecomobility.com
Jose Daniel Fariño Bravo	ASESOR COMERCIAL	Montería - Cauca	318 506 41 04	jdfarino@autecomobility.com
Juan Esteban Castañeda Gaviria	ASESOR COMERCIAL	Mocoa - Putumayo	316 555 26 38	jecastaneda@autecomobility.com
Juan Sebastian Arana Gil	ASESOR COMERCIAL	Tuluá	313 646 30 22	jarana@autecomobility.com
Miguel Angel Guerrero Estupiñan	ASESOR COMERCIAL	Cali - Palmira	314 772 07 98	mguerrero@autecomobility.com
Milton Cesar Olaya Carvajal	ASESOR COMERCIAL	Neiva - Espinal	310 436 27 42	molaya@autecomobility.com
Nancy Potosi Ramirez	ASESOR COMERCIAL	Jamundí	320 697 60 81	npotosi@autecomobility.com
Olga Margarita Vargas Morales	ASESOR COMERCIAL	Cali	300 634 67 59	omvargas@autecomobility.com
Paula Andrea Serna Yepes	ASESOR COMERCIAL	Apartado - Poblaciones Occidente	317 553 26 37	pserna@autecomobility.com
Raul de Jesus Foronda	ASESOR COMERCIAL	Valledupar - Riohacha	312 850 45 74	rforonda@autecomobility.com
Richard Andres Muñoz Montenegro	ASESOR COMERCIAL	Popayán	321 799 79 26	rmunoz@autecomobility.com
Ruben Dario Buitrago Palma	ASESOR COMERCIAL	Yopal	317 479 71 61	rbuitrago@autecomobility.com
Uberney Ortiz Velez	ASESOR COMERCIAL	Medellin Centro	313 672 73 37	uortiz@autecomobility.com
Viviana Mercedes Macias Ballesteros	ASESOR COMERCIAL	Santa Marta - El Banco	318 618 73 68	vmmacias@autecomobility.com
Willintong Cardenas Cenon	ASESOR COMERCIAL	Florencia - Pitalito	310 414 88 45	wcardenas@autecomobility.com
Wilson Sabogal Miranda	ASESOR COMERCIAL	Bucaramanga - Barranca	300 542 85 48	wsabogal@autecomobility.com
Andres Mauricio Alvarez	SUPERNUMERARIO	Pereira	304 496 48 53	amalvarez@autecomobility.com
Diego Fernando Quintana Nuñez	SUPERNUMERARIO	Cali	304 497 36 80	dfquintana@autecomobility.com
Diego Ramirez Castaño	SUPERNUMERARIO	Medellin	318 567 21 89	dramirez@autecomobility.com
Jair Humberto Herrera Savedra	SUPERNUMERARIO		300 541 93 34	jhherrera@autecomobility.com
Jose David Alvarez Castro	SUPERNUMERARIO	Barranquilla	318 575 93 72	jdalvarez@autecomobility.com
Jose Luis Carranza Valencia	SUPERNUMERARIO	Medellin	315 302 77 82	jlarranza@autecomobility.com
Juan Sebastian Defelipe Rodriguez	SUPERNUMERARIO		318 572 83 79	jsdefelipe@autecomobility.com
Pablo Duran Rolon	SUPERNUMERARIO	Bucaramanga	318 572 81 80	pduran@autecomobility.com
Yeison Alberto Buitrago Lara	SUPERNUMERARIO		310 809 93 06	yabuitrago@autecomobility.com
Jorge Alexander Garcia Parra	JEFE DE ZONA	Zona Costa	301 470 07 41	jagarcia@autecomobility.com
Franz Caballero Castro	JEFE DE ZONA	Zona Nororiental	313 584 21 93	fcaballero@autecomobility.com
Hilde Alexander Garcia Cano	JEFE DE ZONA	Zona Occidente	321 641 50 63	hgarcia@autecomobility.com
Jesus Albeiro Lozano Alvarez	JEFE DE ZONA	Zona Sur	304 330 42 49	jalozano@autecomobility.com

SERVICIO AL CLIENTE

LÍNEA ÚNICA DE SERVICIO AL CLIENTE CANAL

(4) 444 81 90 

UNIDAD DE REPUESTOS y ACCESORIOS • FAX OFICINAS: 373 03 75







ATENCIÓN EN:	NOMBRE	E-MAIL	TELÉFONO	FAX
SERVICIO PAGO ANTICIPADO	WILLIAM GARCIA	wgarcia@autecomobility.com		
COORDINADOR SERVICIO POSTVENTA	LUIS G. RODRIGUEZ	lrodriguez@auteco.com.co		
DEVOLUCIONES	DUVI LOPERA VAZQUEZ	dlopera@autecomobility.com		
RECLAMOS	JULIAN RODRIGUEZ	devolucionesrptos@auteco.com.co		
MOTO FUERA DE RUTA	JOSE LUIS BUELVAS SALDARRIAGA	motofueraderuta@auteco.com.co	444 81 90 OPCION (2)	
LÍNEA DE ATENCIÓN AL CLIENTE				

AUTOTECNICA COLOMBIANA S.A.S (AUTECO S.A.S) SEDE PRINCIPAL Cra. 42 N° 45-77 Itagüí Ant. - PBX: (4)306 81 81
Atención a clientes finales: LÍNEA GRATUITA NACIONAL - 01 8000 52 00 90

ÍNDICE

FIGURA Nº	DESCRIPCIÓN	PÁG. Nº	FIGURA Nº	DESCRIPCIÓN	PÁG. Nº
1	CULATA - CILINDRO	1	27	RUEDA TRASERA	30
2	EJE LEVAS - VÁLVULAS	2 - 3	28	PORTA BANDAS TRASERO	31
3	CUBIERTA CLUTCH - CUBIERTA VOLANTE	4	29	SWICHE DE ENCENDIDO	32
4	CLUTCH	5	30	BRAZO OSCILANTE - AMORTIGUADOR TRASERO	33
5	BOMBA ACEITE - FILTRO CENTRIFUGO ACEITE	6	31	SPROCKET - CADENA	34
6	CARCASAS	7 - 8	32	FAROLA - CARENAJE FAROLA	35
7	CIGÜEÑAL - BALANCEADOR - PISTÓN	9	33	VELOCÍMETRO - DIRECCIONALES DELANTERAS	36
8	TRANSMISIÓN	10 - 11	34	ENFOCADORES	37
9	EJE CAMBIOS - EJE SELECTOR CAMBIOS	12	35	TAPA LATERAL - CUBIERTA SILLÍN	38
10	VOLANTE - PLATO BOBINAS	13	36	CUBIERTA STOP	39
11	MOTOR DE ARRANQUE	14	37	GUARDABARRO TRASERO	40
12	CARBURADOR	15	38	STOP - DIRECCIONALES TRASERAS	41
13	COMPLEMENTOS CHASIS - GATO LATERAL	16	39	CABLES	42
14	SOPORTE MOTOR	17	40	SISTEMA ELÉCTRICO	43
15	CAJA FILTRO AIRE	18	41	AGARRADERA PASAJERO	44
16	MANUBRIO - ESPEJOS	19	42	CAJA HERRAMIENTAS	45
17	TANQUE GASOLINA	20	43	VÁLVULA DE AIRE	46
18	SILLÍN	21	44	CALCOMANÍAS Y ACCESORIOS	47
19	SILENCIADOR	22		INDICE DE REFERENCIAS	48 - 51
20	PEDAL CAMBIOS - PEDAL FRENO - PEDAL CRANK	23			
21	REPOSAPIE CONDUCTOR - REPOSAPIE PASAJERO	24			
22	ESPIGA CENTRAL - CABEZA ESPIGA	25			
23	SUSPENSIÓN DELANTERA	26			
24	GUARDABARRO DELANTERO	27			
25	BOMBA FRENO DELANTERO	28			
26	RUEDA DELANTERA	29			

ÍNDICE DE GRÁFICOS

	FIGURA Nº 1: CULATA - CILINDRO PÁG. Nº. 1
	FIGURA Nº 2: EJE LEVAS - VÁLVULAS PÁG. Nº. 2 - 3
	FIGURA Nº 3: CUBIERTA CLUTCH - CUBIERTA VOLANTE PÁG. Nº. 4
	FIGURA Nº 4: CLUTCH PÁG. Nº. 5
	FIGURA Nº 5: BOMBA ACEITE - FILTRO CENTRIFUGO ACEITE PÁG. Nº. 6
	FIGURA Nº 6: CARCASAS PÁG. Nº. 7 - 8

ÍNDICE DE GRÁFICOS




FIGURA N° 7: CIGUEÑAL - BALANCEADOR - PISTÓN

PÁG. N°.
9




FIGURA N° 8: TRANSMISIÓN

PÁG. N°.
10 - 11




FIGURA N° 9: EJE CAMBIOS - EJE SELECTOR CAMBIOS

PÁG. N°.
12




FIGURA N° 10: VOLANTE - PLATO BOBINAS

PÁG. N°.
13




FIGURA N° 11: MOTOR DE ARRANQUE

PÁG. N°.
14









FIGURA N° 12: CARBURADOR

PÁG. N°.
15

ÍNDICE DE GRÁFICOS

	FIGURA N° 13: COMPLEMENTOS CHASIS - GATO LATERAL	PÁG. N°. 16
	FIGURA N° 14: SOPORTE MOTOR	PÁG. N°. 17
	FIGURA N° 15: CAJA FILTRO AIRE	PÁG. N°. 18
	FIGURA N° 16: MANUBRIO - ESPEJOS	PÁG. N°. 19
	FIGURA N° 17: TANQUE GASOLINA	PÁG. N°. 20
	FIGURA N° 18: SILLÍN	PÁG. N°. 21

ÍNDICE DE GRÁFICOS






FIGURA N° 19: SILENCIADOR

PÁG. N°.
22




**FIGURA N° 20: PEDAL CAMBIOS -
PEDAL FRENO - PEDAL CRANK**

PÁG. N°.
23



**FIGURA N° 21: REPOSAPIE CONDUCTOR -
REPOSAPIE PASAJERO**

PÁG. N°.
24



**FIGURA N° 22: ESPIGA CENTRAL -
CABEZA ESPIGA**

PÁG. N°.
25




FIGURA N° 23: SUSPENSIÓN DELANTERA

PÁG. N°.
26







FIGURA N° 24: GUARDABARRO DELANTERO

PÁG. N°.
27

ÍNDICE DE GRÁFICOS

	FIGURA N° 25: BOMBA FRENO DELANTERO		FIGURA N° 26: RUEDA DELANTERA		FIGURA N° 27: RUEDA TRASERA

ÍNDICE DE GRÁFICOS






FIGURA N° 31: SPROCKET - CADENA

PÁG. N°.
34



**FIGURA N° 32: FAROLA -
CARENAJE FAROLA**

PÁG. N°.
35



**FIGURA N° 33: VELOCÍMETRO -
DIRECCIONALES DELANTERAS**

PÁG. N°.
36





FIGURA N° 34: ENFOCADORES

PÁG. N°.
37



**FIGURA N° 35: TAPAS LATERAL -
CUBIERTA SILLÍN**

PÁG. N°.
38










FIGURA N° 36: CUBIERTA STOP

PÁG. N°.
39

ÍNDICE DE GRÁFICOS

	FIGURA N° 37: GUARDABARRO TRASERO PÁG. N°. 40
	FIGURA N° 38: STOP - DIRECCIONALES TRASERAS PÁG. N°. 41
	FIGURA N° 39: CABLES PÁG. N°. 42
	FIGURA N° 40: SISTEMA ELÉCTRICO PÁG. N°. 43
	FIGURA N° 41: AGARRADERA PASAJERO PÁG. N°. 44
	FIGURA N° 42: CAJA HERRAMIENTAS PÁG. N°. 45

ÍNDICE DE GRÁFICOS

			
FIGURA N° 43: VÁLVULA DE AIRE	PÁG. N°. 46	FIGURA N° 44: CALCOMANÍAS Y ACCESORIOS	PÁG. N°. 47

This exploded view diagram illustrates the assembly of a 100cc engine. The components are numbered as follows:

- 1**: Spark plug
- 2**: Spark plug cap
- 3**: Spark plug cap nut
- 4**: Spark plug cap washer
- 5**: Spark plug cap gasket
- 6**: Spark plug cap housing
- 7**: Spark plug cap gasket
- 8**: Spark plug cap gasket
- 9**: Spark plug cap gasket
- 10**: Spark plug cap housing
- 11**: Spark plug cap gasket
- 12**: Spark plug cap gasket
- 13**: Spark plug cap gasket
- 14**: Spark plug cap gasket
- 15**: Spark plug cap gasket
- 16**: Spark plug cap gasket
- 17**: Spark plug cap gasket
- 18**: Spark plug cap gasket
- 19**: Spark plug cap gasket
- 20**: Spark plug cap gasket
- 21**: Spark plug cap gasket
- 22**: Spark plug cap gasket



FIGURA N° 2: EJE LEVAS - VÁLVULAS (1/2)




FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	OBSERVACIÓN
1	100105193	Tornillo 5x14	2	
2	100105158	Tuerca	2	
3	100105168	Tornillo Ajuste Balancín	2	
4	100066671	Balancín	2	
5	100200371	Pasador Balancín	2	
6	100303225	Soporte Balancín (Solo)	1	
7	100100911	Pin Guía 6x10	2	
8	100105183	Soporte Balancín Completo	1	
9	100105320	Cuña Válvula	4	
10	100200691	Arandela Resorte Válvula	2	
11	100200726	Set Resorte Válvula	2	
12	100062531	Reten Válvula	2	
13	100200702	Arandela Resorte Válvula	2	
14	100108485	Válvula Escape	1	
15	100108482	Válvula Admisión	1	
16	100200182	Eje Levas	1	
17	100011264-0003	Tornillo 6x16	2	
18	100053423	Platina Tope Eje Levas	1	
19	100200498	Guía Cadenilla	1	
20	100072152	Piñon Cadenilla Distribucion	1	
21	100011171-0002	Tornillo 6x12	2	
22	100105099	Cadenilla Distribucion	1	
23	100200474	Guía Cadenilla Lado Tensor	1	
24	100208744	Empaque Tensor Cadenilla	1	
25	100200522-0002	Tensor Cadenilla	1	

This diagram illustrates the exploded view of a mechanical assembly, likely a pump or engine component. The parts are numbered 1 through 30. A legend at the top left identifies two types of fasteners: a screw (30) and a bolt (29). The assembly includes a main housing (6) with internal components like valves (3, 4) and a piston/crank mechanism (16, 17, 18). Other parts include a gear (20, 21), a spring (11), a lever (23), and various bolts (24, 25, 26) and screws (9, 10, 12, 13, 14, 15, 19, 27, 28).



FIGURA N° 3: CUBIERTA CLUTCH - CUBIERTA VOLANTE




FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	OBSERVACIÓN
1	100011536-0002	Tornillo 6x30	5	
2	100011538-0003	Tornillo 6x40	8	
3	100104733	Reten 16x28x7	1	
4	100203168-0004	Eje Interno Cubierta Clutch	1	
5	100104759	Reten 12x18x5	1	
6	100103443	Resorte Eje Interno Cubierta Clutch	1	
7	100100636-0001	Pin de Seguridad	1	
8	100206203-0203	Cubierta Clutch	1	
9	100104883	Tapón Nivel Aceite	1	
10	100031573	Anillo Retenedor 18x3	1	
11	100100868	Pin Guía 8x14x6.3	4	
12	100203104-0004	Guía Cable Clutch	1	
13	100208655	Empaque Cubierta Clutch	1	
14	100055591-0006	Tornillo 6x12	1	
15	100206191	Guía Cable Plato Bobinas	1	
16	100208525	Empaque Cubierta Volante	1	
17	100204853-0003	Cubierta Volante	1	
18	100103062-0012	Tapón Cubierta Volante	1	
19	100107733	Anillo Retenedor 27.4x2.65	1	
20	100103059-0012	Tapón Cubierta Volante	1	
21	100138362	Anillo Retenedor 13.2x2.65	1	
22	100011539-0001	Tornillo 6x45	2	
23	100202488-0022	Cubierta Cadena	1	
24	100011537-0002	Tornillo 6x35	8	

This diagram illustrates the exploded view of a mechanical assembly, likely a timing mechanism. The components are numbered 1 through 13:

- 1**: A large gear wheel with 12 teeth.
- 2**: A small circular washer or spacer.
- 3**: A small screw or pin.
- 4**: A small circular washer or spacer.
- 5**: A small square component, possibly a bracket or support.
- 6**: A small screw or pin.
- 7**: A gear wheel with 12 teeth, meshing with gear 1.
- 8**: A gear wheel with 12 teeth, meshing with gear 7.
- 9**: A gear wheel with 12 teeth, meshing with gear 8.
- 10**: A gear wheel with 12 teeth, meshing with gear 9.
- 11**: A small circular washer or spacer.
- 12**: A gear wheel with 12 teeth, meshing with gear 10.
- 13**: A small cylindrical component, possibly a pin or a small gear.

The assembly is shown in a perspective view, with the components arranged in a line along a diagonal axis. The gears are shown in a sequence, indicating their meshing relationship. The components are labeled with numbers 1 through 13, corresponding to the parts list provided in the adjacent table.



FIGURA N° 5: BOMBA ACEITE - FILTRO CENTRIFUGO ACEITE




FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	OBSERVACIÓN
1	100053714	Filtro Centrifugo Aceite	1	
2	100072890	Conducto Filtro Centrifugo Aceite	1	
3	100010978-0001	Tornillo 5x12	3	
4	100104844	Resorte Filtro Centrifugo Aceite	1	
5	100104848	Tapa Campana Filtro Centrifugo Aceite	1	
6	100104850	Pin de Seguridad	1	
7	100208725	Empaque Filtro Centrifugo Aceite	1	
8	100100514	Tuerca M14	1	
9	100103344	Arandela	1	
10	100053715	Campana Filtro Centrifugo Aceite	1	
11	100103496	Piñon Primario	1	
12	100100868	Pin Guía 8x14x6.3	2	
13	100010945-0002	Tornillo 4x8	1	
14	100204512	Platina Cuerpo Bomba Aceite	1	
15	100100190	Rotor Interno Bomba Aceite	1	
16	100100200	Rotor Externo Bomba Aceite	1	
17	100204555	Cuerpo Bomba Aceite	1	
18	100032890	Pin Pasador 2.5x10	1	
19	100032894	Pin Pasador 4x24	1	
20	100204492	Eje Interno Bomba Aceite	1	
21	100100134	Piñon Bomba Aceite	1	
22	100011111	Pin de Seguridad	1	
23	100100056	Bomba Aceite Completa	1	
24	100011537-0002	Tornillo 6x35	2	

FIGURA N° 6: CARCASAS (1/2)




FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	OBSERVACIÓN
1	100100537-0002	Tuerca Tapón 8x63	4	
2	100106609	Arandela 12.5x2x22	4	
3	100100253	Esparrago Carcasa	4	
4	100010556	Pin Guía 10x12	2	
5	100100396	Tornillo de Ajuste 8x30	1	
6	100100868	Pin Guía 8x14x6.3	2	
7	100104941	Filtro Aceite	1	
8	100100984	Rodamiento Bolas 6202	2	
9	100011264-0003	Tornillo 6x16	4	
10	100052343-0003	Carcasa Derecha	1	
11	100011539-0001	Tornillo 6x45	1	
12	100101149	Rodamiento Bolas 6203	1	
13	100011279-0002	Tornillo 6x70	6	
14	100053140	Platina Tope	2	
15	100101050	Rodamiento Bolas 6303-RS	1	
16	100101245	Rodamiento Bolas 6204	1	
17	100101235	Rodamiento Bolas 6201-RS	1	
18	100101111	Rodamiento Bolas 63/28	1	
19	100052342-0003	Carcasa Izquierda	1	
20	100100331-0006	Tapón Drenaje Aceite	1	
21	100106548	Arandela 12.1x2x20	1	
22	100104747	Reten 14x22x5	1	
23	100102998	Pin Guía Platina Tope	1	
24	100103003	Resorte Platina Tope	1	
25	100053422	Platina Tope	1	

This technical diagram illustrates the exploded view of a 2-cylinder engine assembly. The components are numbered as follows:

- 1**: Piston pin
- 2**: Piston pin clip
- 3**: Piston pin clip
- 4**: Piston pin clip
- 5**: Piston pin clip
- 6**: Piston pin clip
- 7**: Piston pin clip
- 8**: Piston pin clip
- 9**: Piston pin clip
- 10**: Piston pin clip
- 11**: Piston pin clip
- 12**: Piston pin clip
- 13**: Piston pin clip
- 14**: Piston pin clip
- 15**: Piston pin clip
- 16**: Piston pin clip
- 17**: Piston pin clip
- 18**: Piston pin clip
- 19**: Piston pin clip
- 20**: Piston pin clip
- 21**: Piston pin clip
- 22**: Piston pin clip
- 23**: Piston pin clip
- 24**: Piston pin clip
- 25**: Piston pin clip
- 26**: Piston pin clip
- 27**: Piston pin clip
- 28**: Piston pin clip
- 29**: Piston pin clip

[illegible]

This technical drawing is an exploded view of a mechanical assembly, likely a pump or motor component. The parts are numbered 1 through 18. The main assembly is shown in a perspective view, with various components separated to show their relative positions and how they fit together. The parts include:

- 1, 3:** Small circular components, possibly washers or spacers.
- 2:** A coiled spring.
- 4:** A small circular component, possibly a washer or spacer.
- 5:** A small circular component, possibly a washer or spacer.
- 6:** A small cylindrical component, possibly a pin or screw.
- 7:** A larger cylindrical component, possibly a housing or cap.
- 8:** A large, complex component, possibly a pump head or motor housing.
- 9, 10, 11:** Components of the main assembly, possibly a pump head or motor housing.
- 12:** A large, complex component, possibly a pump head or motor housing.
- 13:** A small cylindrical component, possibly a pin or screw.
- 14, 15:** Two large, circular components with teeth, possibly gears or impellers.
- 16:** A large, rectangular component, possibly a base plate or housing.
- 17:** A small cylindrical component, possibly a pin or screw.
- 18:** A small cylindrical component, possibly a pin or screw.



FIGURA N° 8: TRANSMISIÓN (1/2)




FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	OBSERVACIÓN
1	100106503	Arandela Caja 12.2x1x22.5	1	
2	100103619	Piñon 2DA Eje Clutch	1	
3	100103623	Piñon 5TA Eje Clutch	1	
4	100103655	Buje Piñon 5TA	1	
5	100103648	Arandela Caja 17x1.6x23	2	
6	100100595	Pin de Seguridad 15.5x1.2x19	2	
7	100103620	Piñon 3RA Eje Clutch	1	
8	100103654	Buje Piñon 4TA	1	
9	100103621	Piñon 4TA Eje Clutch	1	
10	100148341	Eje Clutch (Solo)	1	
11	100106524	Arandela Caja 20.1x1x27	3	
12	100103567	Buje Piñon Eje Salida	2	
13	100103729	Piñon 2DA Eje Salida	1	
14	100103733	Piñon 5TA Eje Salida	1	
15	100203605	Eje Salida (Solo)	1	
16	100103730	Piñon 3RA Eje Salida	1	
17	100103649	Arandela Caja 20x1.6x27	1	
18	100100629	Pin de Seguridad 18.5x1.2x22	1	
19	100103731	Piñon 4TA Eje Salida	1	
20	100106520	Arandela Caja 17.2x1.2x26	2	
21	100103566	Buje Piñon 1RA	1	
22	100103728	Piñon 1RA Eje Salida	1	
23	100106453	Arandela Eje Crank 17.3x1.2x24	2	
24	100011099	Pin de Seguridad	1	
25	100106408	Arandela Eje Crank 14.2x1x34	1	

This exploded view diagram illustrates the assembly of a mechanical component, likely a gear train or a drive mechanism. The parts are numbered 1 through 41. The assembly is shown in three main sections, each enclosed in a perspective box to show its internal structure.

- Top Section:** Contains parts 1 through 10. It features a series of gears (1, 2, 3, 4, 5, 6, 7, 8, 9, 10) mounted on a shaft (10). A small component (39) is shown separately.
- Middle Section:** Contains parts 11 through 22. It shows a central shaft (15) with various gears (11, 12, 13, 14, 16, 17, 18, 19, 20, 21, 22) and a spring (12) mounted on it. A small component (34) is also shown.
- Bottom Section:** Contains parts 23 through 41. It shows a shaft (31) with gears (23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41) and a spring (40) mounted on it. A small component (41) is also shown.

The diagram uses perspective views to show the internal arrangement of the parts and their relative positions within the assembly.



This diagram illustrates the exploded view of a mechanical assembly, with components numbered 1 through 19. The parts are distributed as follows:

- Top Assembly (12):** A large rectangular plate with a complex bracket on the left and a long shaft (9) extending to the right. The shaft has a black and white striped section near its end.
- Shaft Components (9, 14, 15, 16):** A long shaft (9) is shown separately. At its right end, there is a spring (14), a ring (15), and another ring (16).
- Intermediate Components (8, 10, 11):** A short shaft (8) is shown. Below it are two U-shaped brackets (10) and two more U-shaped brackets (11) with circular openings.
- Base and Fasteners (1, 2, 3, 4, 5, 6, 7, 13, 17, 18, 19):**
 - A bolt (1) and a washer (2) are shown near a curved bracket (3).
 - A spring (4) is shown below the bracket (3).
 - A bolt (5) and a star-shaped washer (6) are shown near a cylindrical component (7).
 - A small bracket (13) and a bolt (19) are shown near the bottom right.
 - Two long screws (18) are shown near the bottom right.
 - A star-shaped washer (17) is shown near the cylindrical component (7).

[illegible]

This diagram illustrates the assembly of a vehicle's rear wheel. The components are labeled as follows:

- 1**: The rear wheel, showing the tire and the hub area with mounting tabs.
- 2**: A cable or hose that connects the wheel hub to a control unit.
- 3**: Two small electrical connectors or pins that plug into the control unit.
- 4**: Four screws used to secure the control unit to the wheel hub.



This diagram illustrates the assembly of a mechanical component, likely a pump or motor. The main body (2) is a cylindrical unit with a central shaft. Two screws (1) are used to secure the top cover. A flexible hose is connected to the side of the body. The shaft is fitted with a series of gears: a small pinion (3) on the shaft, a small gear (4) meshing with it, a medium gear (5) meshing with gear 4, and a large gear (6) meshing with gear 5. A large gear (7) is shown separately, which would mesh with gear 6. A small pin (3) is also shown separately, likely for the shaft.

[illegible]

This diagram illustrates the exploded view of a carburetor assembly. The components are labeled as follows:

- 1:** Two screws used to secure the float valve.
- 2:** The float valve body, which houses the float and needle valve mechanism.
- 3:** The main carburetor body, including the throttle cable linkage and jetting components.
- 4:** Two small O-rings or seals used for the float valve assembly.



This diagram illustrates the assembly of a vehicle chassis, showing the main frame and various associated components. The parts are numbered as follows:

- 1**: Small circular fasteners or pins.
- 2**: A vertical support or shock absorber component.
- 3**: A small pin or bolt.
- 4**: A small circular fastener or pin.
- 5**: A small pin or bolt.
- 6**: A vertical support or shock absorber component.
- 7**: A set of horizontal bars or springs.
- 8**: Small circular fasteners or pins.
- 9**: A small pin or bolt.
- 10**: A set of horizontal bars or springs.
- 11**: A small circular fastener or pin.
- 12**: A large, dark, curved component, possibly a fender or wheel arch.
- 13**: A bracket or support for the large curved component.
- 14**: Small circular fasteners or pins.
- 15**: A set of horizontal bars or springs.

[illegible]

This diagram illustrates the assembly of a mechanical component, likely a bracket or support structure, using 14 numbered parts. The components are as follows:

- 1:** Two long vertical bolts.
- 2:** Two medium-length vertical bolts.
- 3:** Two black triangular plates with three mounting holes each.
- 4:** Two small circular spacers or washers.
- 5:** Two large circular washers.
- 6:** Four medium circular washers, shown in two groups of two.
- 7:** Two small horizontal bolts.
- 8:** A small black triangular plate with three mounting holes.
- 9:** Two small square spacers or washers.
- 10:** A small horizontal bolt.
- 11:** A small circular washer.
- 12:** A small circular washer.
- 13:** A long horizontal base plate with a central mounting hole and curved ends.
- 14:** Two medium-length vertical bolts.

The assembly process involves attaching the triangular plates (3 and 8) to the base plate (13) using the bolts (1, 2, 14) and various washers (5, 6, 11, 12) and spacers (4, 9) to ensure proper alignment and spacing.



Diagram illustrating the components of a motorcycle helmet assembly, labeled 1 through 5:

- 1: Main helmet shell (outer and inner parts).
- 2: Bolt/screw.
- 3: Washer/spacer.
- 4: Chin strap buckle.
- 5: Chin strap padding/liner.

[illegible]

This diagram illustrates the components of a motorcycle handlebar assembly. The main assembly consists of a central handlebar (2) with two side mirrors (1) mounted on the left and a single mirror (3) on the right. Below the handlebar, various accessories are shown, including a handgrip (4), a handgrip (5), a handgrip (6), a handgrip (7), a handgrip (8), a handgrip (9), a handgrip (10), a handgrip (11), a handgrip (12), a handgrip (13), a handgrip (14), a handgrip (15), a handgrip (16), a handgrip (17), a handgrip (18), a handgrip (19), and a handgrip (20). The components are arranged in a way that shows their relative positions and how they fit together.



This diagram shows the exploded view of a motorcycle fuel tank assembly. The main component is the fuel tank (4). The exploded parts are numbered as follows:

- 1: A bolt.
- 2: A circular gasket or seal.
- 3: A rectangular plate or cover.
- 4: The main fuel tank body.
- 5: A petcock assembly with a lever.
- 6: A small pin or clip.
- 7: Two circular gaskets or seals.
- 8: A small pin or clip.
- 9: A curved metal bracket or support.
- 10: A long metal rod or pin.
- 11: A small pin or clip.

[illegible]

The diagram shows a black motorcycle seat with the brand name "outeco" printed on the right side. Below the seat, there are two sets of hardware. The first set, labeled "2", consists of two black plastic mounting brackets. The second set, labeled "3", consists of two metal washers or spacers. A line from the number "1" points to the seat, indicating the assembly area.



This diagram illustrates the assembly of a boat outboard motor. The components are numbered as follows:

- 1**: Upper mounting bracket
- 2**: O-ring
- 3**: Main outboard motor housing
- 4**: Lower motor housing / transom bracket
- 5**: Propeller shaft bracket
- 6**: Propeller shaft
- 7**: Propeller
- 8**: Propeller nut
- 9**: Propeller pin
- 10**: Propeller lock pin
- 11**: Propeller pin
- 12**: Propeller lock pin
- 13**: Propeller pin
- 14**: Propeller lock pin
- 15**: Propeller pin
- 16**: Propeller lock pin

[illegible]

This diagram illustrates the assembly of a mechanical device, likely a pump or actuator, using 15 numbered components. The components are arranged in an exploded view to show their relative positions and assembly sequence.

- Component 1:** A curved, dark-colored arm or lever.
- Component 2:** A small, cylindrical pin or fastener.
- Component 3:** A small, cylindrical pin or fastener.
- Component 4:** A long, straight, dark-colored arm or lever.
- Component 5:** A small, rectangular plate or washer.
- Component 6:** A long, straight, dark-colored arm or lever.
- Component 7:** A small, rectangular plate or washer.
- Component 8:** A small, circular washer or spacer.
- Component 9:** A small, circular washer or spacer.
- Component 10:** A small, rectangular plate or washer.
- Component 11:** A small, rectangular plate or washer.
- Component 12:** A long, straight, dark-colored arm or lever.
- Component 13:** A small, rectangular plate or washer.
- Component 14:** A small, circular washer or spacer.
- Component 15:** A small, rectangular plate or washer.

The assembly is shown in a disassembled state, with components 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, and 15 arranged in a way that suggests their relative positions and assembly sequence. The components are numbered 1 through 15, with 1 through 11 being dark-colored and 12 through 15 being light-colored.



This diagram illustrates the assembly of a mechanical component, likely a bracket or support, using 17 numbered parts. The components are distributed across four panels:

- Top Left Panel:** Shows five small components: a long bolt (9), a small nut (10), a washer (11), a short bolt (12), and a small washer (13).
- Top Right Panel:** Shows five more small components: a long bolt (7), a small nut (10), a washer (11), a short bolt (12), and a small washer (13).
- Bottom Left Panel:** Shows a large bracket (1) with a mounting flange (2) and a small nut (6). It also shows a set of four screws (5) and a small bracket (3).
- Bottom Right Panel:** Shows a large bracket (4) with a mounting flange (8) and a small nut (14). It also shows a set of four screws (15) and a small bracket (16).

The assembly process involves attaching the mounting flanges (1 and 2) to the brackets (3 and 4) using the bolts (9 and 7) and nuts (10). The screws (5 and 15) are used to secure the brackets to the mounting flanges. The small brackets (6 and 14) are attached to the brackets (3 and 4) using the short bolts (12) and washers (13).

[illegible]

This diagram illustrates the exploded view of a mechanical assembly, with components labeled as follows:

- 1**: Main upper bracket or housing.
- 2**: Four small circular fasteners or washers.
- 3**: Central vertical shaft or tube.
- 4**: Two small rectangular plates or spacers.
- 5**: A single hexagonal nut.
- 6**: A single hexagonal nut.
- 7**: A single hexagonal nut.
- 8**: Three circular components, likely seals or gaskets, shown in a dashed box.
- 9**: A circular flange or ring.
- 10**: A circular flange or ring.
- 11**: Two circular flanges or rings.
- 12**: A circular flange or ring.
- 13**: A circular flange or ring.
- 14**: A small L-shaped bracket or pin.
- 15**: Main lower bracket or housing.
- 16**: Two long screws or bolts.
- 17**: Four short screws or bolts.
- 18**: A circular cap or plug.



Diagram 1 shows a vertical assembly with the following components labeled:

- 1: Main vertical shaft
- 2: Small circular component
- 3: Small circular component
- 4: Small circular component
- 5: Small circular component
- 6: Small circular component
- 7: Small circular component
- 8: Small circular component
- 9: Small circular component
- 10: Small circular component
- 11: Small circular component
- 12: Small circular component
- 13: Small circular component
- 14: Small circular component
- 15: Small circular component
- 16: Small circular component
- 17: Small circular component
- 18: Small circular component
- 19: Small circular component
- 20: Small circular component
- 21: Small circular component

Diagram 2 shows a vertical assembly with the following components labeled:

- 1: Main vertical shaft
- 2: Small circular component
- 3: Small circular component
- 4: Small circular component
- 5: Small circular component
- 6: Small circular component
- 7: Small circular component
- 8: Small circular component
- 9: Small circular component
- 10: Small circular component
- 11: Small circular component
- 12: Small circular component
- 13: Small circular component
- 14: Small circular component
- 15: Small circular component
- 16: Small circular component
- 17: Small circular component
- 18: Small circular component
- 19: Small circular component
- 20: Small circular component
- 21: Small circular component

[illegible]

This exploded view diagram illustrates the components of a motorcycle rear fender assembly. The parts are numbered as follows:

- 1**: The main black rear fender body.
- 2**: A black mounting bracket.
- 3**: A white plastic fender liner.
- 4**: A white plastic fender liner.
- 5**: A small black mounting bracket.
- 6**: A small black mounting bracket.
- 7**: A small black mounting bracket.
- 8**: A small black mounting bracket.
- 9**: A black mounting bracket.
- 10**: A black mounting bracket.
- 11**: A set of six screws.
- 12**: A set of six washers.
- 13**: A set of six screws.



This diagram illustrates the components of a motorcycle rear brake system. The parts are numbered as follows:

- 1**: Brake lever assembly, shown in a dashed box with sub-part **11**.
- 2**: Small mounting pin or bush.
- 3**: Brake master cylinder.
- 4**: Long brake line connecting the master cylinder to the wheel.
- 5**: Small metal bracket or clip.
- 6**: Brake caliper assembly, shown in a dashed box.
- 7**: Brake pump or actuator.
- 8**: Two mounting bolts.
- 9**: Four mounting bolts for the disc.
- 10**: Brake disc (rotor).
- 12**: A single mounting pin or bolt.

[illegible]

This diagram illustrates the components of a bicycle wheel assembly, numbered 1 through 16:

- 1**: Tire
- 2**: Tire patch
- 3**: Tire patch
- 4**: Long bolt
- 5**: Small bolt
- 6**: Small bolt
- 7**: Cable end
- 8**: Small bolt
- 9**: Small bolt
- 10**: Small bolt
- 11**: Small bolt
- 12**: Wheel rim
- 13**: Spoke
- 14**: Spoke
- 15**: Spoke
- 16**: Spoke



This diagram illustrates the components of a bicycle wheel assembly, numbered 1 through 17. The parts are as follows:

- 1**: The main tire assembly, including the tire and rim.
- 2**: A small black rectangular component, likely a fender or mudguard.
- 3**: A small black rectangular component, likely a fender or mudguard.
- 4**: A small black circular component, likely a hub or axle end cap.
- 5**: A small black circular component, likely a hub or axle end cap.
- 6**: A small black rectangular component, likely a fender or mudguard.
- 7**: A small black rectangular component, likely a fender or mudguard.
- 8**: A long black cylindrical component, likely an axle or shaft.
- 9**: Two small black components, likely fenders or mudguards, shown in a dashed box.
- 10**: A small black circular component, likely a hub or axle end cap.
- 11**: A small black circular component, likely a hub or axle end cap.
- 12**: A small black rectangular component, likely a fender or mudguard.
- 13**: A small black rectangular component, likely a fender or mudguard.
- 14**: A small black rectangular component, likely a fender or mudguard.
- 15**: A small black circular component, likely a hub or axle end cap.
- 16**: A small black rectangular component, likely a fender or mudguard.
- 17**: A small black rectangular component, likely a fender or mudguard.

[illegible]



The image displays several motorcycle accessories. On the left, a black handlebar grip with a silver tip and a black cable is shown. To its right is a blue circular light with a clear lens. Below the blue light is a black rectangular light with a silver lens. To the right of the rectangular light is a keychain with two keys. On the far left, a small electronic component is shown with three labels: 1, 2, and 3.

[illegible]

This diagram shows an exploded view of a mechanical assembly. The components are numbered as follows:

- 1:** A small pin or screw.
- 2:** A larger pin or screw.
- 3:** A small circular washer or spacer.
- 4:** A coiled metal spring.
- 5:** A curved metal bracket or lever.
- 6:** A small pin or screw.
- 7:** A small circular washer or spacer.
- 8:** A long, thin vertical rod.
- 9:** A small circular washer or spacer.
- 10:** A pair of small circular washers or spacers.
- 11:** A large, complex metal frame or housing.
- 12:** A small circular washer or spacer.
- 13:** A small rectangular plate or shim.
- 14:** A small rectangular plate or shim.

The assembly is shown in a disassembled state, with the parts arranged to show their relative positions and how they fit together. The large frame (11) is the central component, with the spring (4) and bracket (5) attached to its top. The rod (8) is positioned vertically, and the washers (9, 10, 12) are shown at various points of contact.



This diagram illustrates the components of a motorcycle rear wheel assembly in an exploded view. The parts are numbered as follows:

- 1**: Rear fender, a black plastic cover with four circular cutouts.
- 2**: Drive chain, a metal roller chain.
- 3**: Rear sprocket, a metal gear with 16 teeth.
- 4**: Two pins for the chain to the fender.
- 5**: Four O-rings for the chain to the fender.
- 6**: Two pins for the chain to the sprocket.
- 7**: Five pins for the fender to the frame.
- 8**: Four O-rings for the fender to the frame.
- 9**: Rear axle, a metal shaft with a central nut and lock washer.
- 10**: Rear axle nut, a metal nut for the axle.

[illegible]

This diagram illustrates the components of a motorcycle headlight assembly, numbered 1 through 13:

- 1**: The main headlight housing with a lens and a wiring harness.
- 2** and **3**: Two different styles of mounting brackets.
- 4**: Three small circular fasteners (screws or bolts) for the bracket.
- 5**: Three small circular fasteners (screws or bolts) for the bracket.
- 6**: Two small vertical pins or spacers.
- 7**: A triangular mounting plate with three circular cutouts.
- 8**: Three small circular fasteners (screws or bolts) for the plate.
- 9** and **10**: Two long, black, textured mounting arms or handles.
- 11**: Two small circular fasteners (screws or bolts) for the arm.
- 12**: Two small circular fasteners (screws or bolts) for the arm.
- 13**: Three small circular fasteners (screws or bolts) for the arm.



Exploded view diagram of a motorcycle fender assembly. The components are labeled as follows:

- 1: Main fender body (left side)
- 2: Fender tip (right side)
- 3: Main fender body (right side)
- 4: Fender tip (left side)
- 5: Screws (two types shown)
- 6: Washers (two types shown)
- 7: Nuts (three types shown)

[illegible]

1

2

3

4

5



An exploded view diagram of a mechanical assembly. The components are numbered as follows:

- 1**: A large, dark, curved main housing or bracket.
- 2**: A small, rectangular red component, likely a light or indicator.
- 3**: A long, dark, U-shaped component, possibly a base or support.
- 4**: Two small, square, light-colored components, possibly sensors or switches.
- 5**: A bracket or connector piece with two circular holes.
- 6**: Two screws or bolts.
- 7**: Two screws or bolts.
- 8**: Three small, circular, light-colored components, possibly washers or spacers.

[illegible]

This diagram illustrates the components of a motorcycle headlight assembly in an exploded view. The parts are numbered as follows:

- 1**: The main headlight housing, shown in the center.
- 2**: A wiring harness with a coiled cable and a connector.
- 3**: A small, cylindrical component, likely a fuse or a small bulb.
- 4**: A pair of mounting brackets or spacers.
- 5**: A pair of mounting brackets or spacers, similar to 4 but with different hole patterns.
- 6**: A long, narrow, black component, likely a side marker light or a turn signal.
- 7**: Another long, narrow, black component, identical to 6.
- 8**: A central mounting bracket or plate that would hold the side lights in place.



Diagram 1: A cable with a black connector at the top and a threaded metal fitting at the bottom.

Diagram 2: A cable with a small metal fitting at the top and a threaded metal fitting at the bottom.

[illegible]

This image displays 14 individual automotive components, each labeled with a number from 1 to 14. The components are arranged as follows:

- 1:** A small electronic control module with two pins.
- 2:** A short cable with a multi-colored connector.
- 3:** A bracket or mounting hardware.
- 4:** A long cable with a multi-colored connector.
- 5:** A fuse block with multiple fuses.
- 6:** A small black rectangular component.
- 7:** A small black rectangular component.
- 8:** A small black rectangular component.
- 9:** A cable with a multi-colored connector.
- 10:** A cable with a multi-colored connector.
- 11:** A small black rectangular component.
- 12:** A circular horn or speaker.
- 13:** A bracket or mounting hardware.
- 14:** A rectangular battery with "VARTA" branding.



This diagram illustrates the assembly of a rear suspension component, likely a rear cross-member or control arm bracket. The main component is labeled 1. The assembly includes the following parts:

- 2:** Two long bolts, one for the top and one for the bottom mounting points.
- 3:** Two shorter bolts, one for the top and one for the bottom mounting points.
- 4:** Four washers, two for the top and two for the bottom mounting points.
- 5:** Two larger washers, one for the top and one for the bottom mounting points.
- 6:** Two small washers, one for the top and one for the bottom mounting points.
- 7:** Two small nuts, one for the top and one for the bottom mounting points.

[illegible]

This diagram illustrates the components and tools required for the seat assembly. The parts are numbered as follows:

- 1:** A black plastic bag, likely for the seat cover or a protective layer.
- 2:** Two small screws used for securing the seat base.
- 3:** A set of three small circular components, possibly spacers or washers.
- 4:** A black metal bracket or frame component.
- 5:** The main black plastic seat shell.
- 6:** Two screws used for mounting the seat to the frame.
- 7:** A black leather or vinyl seat strap with metal end fittings.
- 8:** A metal bracket or support piece.

The tools shown include a screwdriver, a small wrench, a larger wrench, a long thin rod, and a black plastic cap or plug.



This diagram illustrates the components of a rear window heating system, numbered 1 through 8. The components include:

- 1:** A rectangular control unit with a circular connector on one side.
- 2:** A small electrical connector or plug.
- 3:** A small electrical connector or plug, similar to component 2.
- 4:** A short, curved black heating cable with a connector at one end.
- 5:** A long, curved black heating cable with connectors at both ends.
- 6:** A long, straight black heating cable with a connector at one end and a terminal at the other.
- 7:** A short, curved black heating cable with a connector at one end and a terminal at the other.
- 8:** A vertical assembly consisting of a control switch, a fuse holder, and a fuse, connected to a wiring harness.

[illegible]

FIGURA N° 44: CALCOMANÍAS Y ACCESORIOS




FIG. No.	PARTE N°	DESCRIPCIÓN	CANT.	OBSERVACIÓN
1	CAL100L001-1	Calcomanía Logo Victory	1	
2	CAL125C002-1	Calcomanía Carenaje Superior Farola Derecha	1	Moto Negro/Blanco
	CAL125C002-2		1	Moto Gris/Amarillo - Negro/Rojo
3	CAL125C003-1	Calcomanía Carenaje Superior Farola Izquierda	1	Moto Negro/Blanco
	CAL125C003-2		1	Moto Gris/Amarillo - Negro/Rojo
4	CAL125C004-1	Calcomanía Guardabarro Delantero Derecha	1	Moto Negro/Blanco
	CAL125C004-2		1	Moto Gris/Amarillo - Negro/Rojo
5	CAL125C005-1	Calcomanía Guardabarro Delantero Izquierda	1	Moto Negro/Blanco
	CAL125C005-2		1	Moto Gris/Amarillo - Negro/Rojo
6	CAL125C006-1	Calcomanía Protector Tubo Telescópico Der.	1	Moto Negro/Blanco
	CAL125C006-2		1	Moto Gris/Amarillo - Negro/Rojo
7	CAL125C007-1	Calcomanía Protector Tubo Telescópico Izq.	1	Moto Negro/Blanco
	CAL125C007-2		1	Moto Gris/Amarillo - Negro/Rojo
8	CAL125C012-1	Calcomanía Enfocador Superior Derecha	1	Moto Negro/Blanco - Negro/Rojo
	CAL125C012-2		1	Moto Gris/Amarillo
9	CAL125C013-1	Calcomanía Enfocador Superior Izquierda	1	Moto Negro/Blanco - Negro/Rojo
	CAL125C013-2		1	Moto Gris/Amarillo
10	CAL125C008-1	Calcomanía Enfocador Inferior Derecha	1	Moto Negro/Blanco - Negro/Rojo
	CAL125C008-2		1	Moto Gris/Amarillo
11	CAL125C009-1	Calcomanía Enfocador Inferior Izquierda	1	Moto Negro/Blanco - Negro/Rojo
	CAL125C009-2		1	Moto Gris/Amarillo
12	21005552/00	Calcomanía Tapa Lateral Derecha "EURO3"	1	
13	CAL125C010-1	Calcomanía Cubierta Sillín Derecha	1	Moto Negro/Blanco - Negro/Rojo
	CAL125C010-2		1	Moto Gris/Amarillo
14	CAL125C011-1	Calcomanía Cubierta Sillín Izquierda	1	Moto Negro/Blanco - Negro/Rojo
	CAL125C011-2		1	Moto Gris/Amarillo
15	21005402/00	PUFF Manubrio	1	

ÍNDICE DE REFERENCIAS

PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.
06000-1126-C100	1	45	100011536-0002	23	4	100073664	8	9	100101111	18	7	100103623	3	10
07002-1853-C40002	1	32	100011537-0002	24	4	100085749	16	9	100101138	10	9	100103648	5	10
08122-M154-000001	10	35	100011537-0002	24	6	100091807	15	9	100101149	12	7	100103649	17	10
08216-0000-0300	9	16	100011538-0003	2	4	100091808	14	9	100101235	17	7	100103654	8	10
08216-0000-0700	7	16	100011539-0001	22	4	100100056	23	6	100101245	16	7	100103655	4	10
08216-0000-0900	10	16	100011539-0001	11	7	100100134	21	6	100101400	7	9	100103728	22	10
100010556	12	1	100031573	10	4	100100190	15	6	100101503	6	9	100103729	13	10
100010556	4	7	100031911-0004	39	11	100100200	16	6	100101607	2	9	100103730	16	10
100010669	4	5	100032890	18	6	100100253	3	7	100102007	18	9	100103731	19	10
100010945-0002	13	6	100032894	19	6	100100331-0006	20	7	100102726	7	1	100103733	14	10
100010978-0001	3	6	100052342-0003	19	7	100100389	1	12	100102822	14	1	100103781	35	11
100011096	15	12	100052343-0003	10	7	100100396	5	7	100102852-0003	5	1	100103819	37	11
100011098	30	11	100053140	14	7	100100407-0004	3	1	100102998	23	7	100103850	38	11
100011099	24	10	100053422	25	7	100100514	8	6	100103003	24	7	100103972	14	12
100011111	22	6	100053423	18	2	100100537-0002	1	7	100103059-0012	20	4	100103986	4	12
100011170-0003	4	13	100053424	3	14	100100545-0001	1	9	100103062-0012	18	4	100104154	9	1
100011171-0002	21	2	100053425	5	14	100100580	5	9	100103244	4	14	100104241-0049	2	14
100011174-0004	5	12	100053426	6	12	100100595	6	10	100103342	11	5	100104500-0002	13	12
100011261-0004	1	1	100053714	1	6	100100629	18	10	100103344	9	6	100104517	8	1
100011264-0003	21	1	100053715	10	6	100100636-0001	7	4	100103354	13	5	100104703	27	8
100011264-0003	17	2	100053886	4	9	100100640	13	9	100103394	6	5	100104733	3	4
100011264-0003	9	7	100055588-0006	26	3	100100643	11	9	100103443	6	4	100104747	22	7
100011264-0003	13	7	100055589-0006	26	8	100100868	29	3	100103496	11	6	100104759	5	4
100011268-0003	18	12	100055589-0006	3	13	100100868	11	4	100103566	21	10	100104844	4	6
100011268-0003	1	14	100055591-0006	14	4	100100868	12	6	100103567	12	10	100104848	5	6
100011273-0003	29	8	100057104	18	1	100100868	6	7	100103569	17	9	100104850	6	6
100011279-0002	28	3	100062531	12	2	100100887	17	12	100103572	9	9	100104883	9	4
100011279-0002	30	8	100066615	22	1	100100911	7	2	100103578	41	11	100104941	7	7
100011285-0001	16	1	100066671	4	2	100100984	8	7	100103619	2	10	100105099	22	2
100011533-0005	3	5	100072152	20	2	100101017	6	14	100103620	7	10	100105158	2	2
100011536-0002	1	4	100072890	2	6	100101050	15	7	100103621	9	10	100105168	3	2

ÍNDICE DE REFERENCIAS

PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.
100105183	8	2	100200182	16	2	100203888	12	12	17100-0000-130003	3	15	3241A-I853-000001	17	24
100105193	1	2	100200371	5	2	100203962	3	12	18000-I853-050003	3	22	32420-I853-000065	4	24
100105320	9	2	100200474	23	2	100204492	20	6	18030-I111-0000	2	22	3242E-I853-000001	8	24
100105492-0002	20	1	100200498	19	2	100204512	14	6	18040-I853-010066	8	22	32618-I853-0000	6	24
100105731	32	11	100200522-0002	25	2	100204555	17	6	18040-I853-020001	5	22	33300-I853-C30065	4	33
100105747	33	11	100200691	10	2	100204853-0003	17	4	18040-I853-C00066	7	22	34100-I111-C10001	1	26
100105776	29	11	100200702	13	2	100205137-0007	2	13	1804L-I853-020001	4	22	34102-I111-010000	9	26
100105786	26	11	100200726	11	2	100205285	1	13	1804M-I853-C20066	6	22	34103-I111-0000	10	26
100106364	3	9	100201878	40	11	100206191	15	4	18070-0000-110014	17	22	34105-I111-0000	16	26
100106373	2	12	100201916	31	11	100206203-0203	8	4	18090-G279-0000	1	46	34106-I111-0000	17	26
100106408	25	10	100201921	36	11	100207098	12	9	18092-0000-300001	4	46	34107-I111-0000	15	26
100106433	28	11	100202488-0022	25	4	100208447	6	1	21005400	1	21	34108-I111-000001	18	26
100106453	23	10	100202731	7	14	100208525	16	4	21005402/00	15	47	34109-I111-000001	4	26
100106453	34	11	100202745	27	3	100208590	15	1	21005552/00	12	47	34111-J1R5-000001	9	27
100106503	1	10	100202833	1	5	100208655	13	4	21006249	4	21	34112-I111-000000	11	26
100106520	20	10	100202920	7	5	100208725	7	6	21200-I111-020068	4	23	3411G-I111-00000G	3	26
100106524	11	10	100202938	5	5	100208744	24	2	24400-I853-000067	1	23	3411X-I853-00006N	7	27
100106538	2	1	100202952	10	5	100208765	19	1	26400-428H-0128	2	34	3411Y-I853-00006N	5	27
100106548	21	7	100202996	12	5	100208911	4	1	31110-I853-C300	12	16	34120-I111-00000G	7	26
100106609	2	7	100203033	8	5	100300796	16	12	32102-I853-00000L	5	16	34121-I111-010000	8	26
100107733	19	4	100203061	9	5	100303225	6	2	32108-I853-C1001X	9	24	34122-I111-0000	14	26
100107753	17	1	100203082	2	5	100303334	28	8	32108-I853-C2001X	7	24	34123-I111-010000	12	26
100107799	30	3	100203104-0004	12	4	100303346	27	11	32110-I853-010068	1	24	34127-I111-000000	20	26
100108432-0002	13	1	100203168-0004	4	4	110/90-17-MR923-TT	1	30	32112-I853-C10001	12	24	34132-I111-000000	21	26
100108440-0003	10	1	100203549	42	11	12162-LOM1-0000	8	46	32114-I853-C10001	10	24	34135-I111-000000	13	26
100108482	15	2	100203605	15	10	15800-I853-C400	2	15	32120-I853-020068	2	24	34144-I111-000000	19	26
100108485	14	2	100203722	11	12	16100-J0S8-000002	1	18	32130-I853-010065	2	16	34145-I111-000000	5	26
100108521	11	1	100203750	10	12	16101-I853-C000	5	18	32305-I853-00006N	8	17	34183-I853-00006N	6	27
100120663	19	12	100203759	8	12	16156-0000-2000	7	46	32327-I853-00006N	3	17	34184-I853-00006N	8	27
100138362	21	4	100203761	9	12	16156-0000-460001	6	46	32328-I853-00006N	4	17	34200-I111-C10001	2	26
100148341	10	10	100203796	7	12	17010-I111-000001	10	19	32410-I853-000065	3	24	34212-I853-C2000P	3	27

ÍNDICE DE REFERENCIAS

PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.
34213-I853-C2000P	4	27	51181-I301-00001X	4	29	6222A-0000-1200	15	16	71105-I853-000001	7	25	72400DZZ0B508081C	2	42
35001-I853-0000	5	33	51201-I219-00001X	6	30	6222A-0000-1200	12	36	71106-I853-000001	5	25	72600AZZ28009351C	1	42
35010-J0A2-000001	9	30	51202-I853-00001X	7	30	6222A-0000-1200	5	39	7110B-I853-0000	18	25	81100-H418-0000	10	43
35110-I853-0200	1	34	51205-0000-120000	3	30	6222A-0000-5400	11	16	7111A-I853-C30065	4	25	81200-J949-0200	7	43
35200-I853-000065	11	33	51205-0000-130000	2	29	6222A-I853-0000	10	22	7111J-I853-C00065	15	25	81301-H418-C100	9	43
35201-J150-0000	10	33	51214-0000-070066	15	30	62514-I853-0000	8	35	71120-I853-000065	3	25	82290-I126-0500	8	43
3520B-I853-0000	14	33	51281-I126-00001X	8	30	63104-J1R5-010007	1	27	71124-I853-0000	8	25	83100-H259-C000	5	43
35241-I853-0000	13	33	52100-I853-000065	6	23	63106-J1R5-000001	2	27	7112B-I853-C10001	6	25	83210-G271-C000	7	45
35281-I853-C0001X	8	33	52105-I853-000002	5	23	63201-I853-C100	1	40	71183-I853-C0006N	5	28	83220-I853-C10065	4	45
35316-I853-C200	3	34	52200-I853-010001	12	23	63206-I853-C00065	3	40	71183-I853-C1006N	2	28	84600-I853-0100	2	43
38001-J1R5-000001	8	45	53001-I853-0100	10	28	63301-J1R5-010007	2	38	71185-I853-030065	10	27	84602-I853-C00002	11	23
41075-2719/18	3	29	53002-I853-030001	4	28	63323-J1R5-010007	4	38	71201-I853-0000	9	25	85100-I853-C50007	3	43
41075-3217/18	2	30	53012-I853-0100	3	28	63333-J1R5-010007	1	38	71202-I853-0000	13	25	85105-J1R5-000001	14	25
42154-I853-0000	15	22	53013-I853-000001	6	28	63341-J1R5-010007	3	38	71203-I853-0000	10	25	85111-0000-0200	4	43
42200-I853-000066	1	44	53014-I853-C000	7	28	63342-H206-0100	12	17	71204-I853-0000	12	25	85120-I853-C400	11	28
51101-I853-030006	5	29	54205-I853-000066	2	31	63342-H206-0100	8	36	71208-I853-0000	11	25	85171-0000-0100	1	43
51108-0000-1200	4	30	54206-I853-0000	4	31	63346-J486-0100	6	37	72010-I111-020065	4	19	85500-I219-010065	12	43
5110A-0000-0600	10	29	54207-I853-000001	1	31	63346-J486-0100	6	38	72020-I111-020065	11	19	85600-I853-C000	6	43
51112-0000-150066	17	30	54208-I853-000001	9	31	63373-J1R5-010007	1	37	72053-I245-C000	8	19	85830-I853-C100	2	40
51112-0000-A30066	12	29	54209-I853-000001	8	31	63374-J1R5-010007	2	37	72100-I853-02006N	2	19	86100-I853-C10006	3	35
51113-1032-2085	13	29	54212-I853-0000	5	31	63404-I853-010065	13	17	72201-I853-C00001	5	19	86160-0000-C390	4	35
51113-2032-2080	14	29	54220-I853-020000	3	31	63436-I111-0000	2	39	72204-I853-C00001	18	19	86200-I853-C130	1	41
51114-1040-1485	14	30	55002-I111-120001	9	34	63504-I853-C000	11	35	72205-I853-C00001	17	19	86202-I853-000000	2	41
51114-2040-1480	13	30	61100-J1R5-010007	4	20	63550-I853-C300	2	35	72206-I853-000001	13	19	86203-I853-010065	8	41
51115-0000-230066	15	29	61111-I377-0000	7	20	63551-J1R5-000001	12	35	72209-I853-000067	7	19	86260-0000-C220	3	41
51116-0000-0300	8	29	61112-I853-0000	3	20	63602-J1R5-010007	1	39	72217-I853-000001	19	19	86300-J1R5-000001	9	36
51116-0000-0400	10	30	61150-M567-0000	5	20	63710-L0M1-0000	5	45	72218-I853-000001	15	19	86307-J1R5-000001	2	36
51117-0000-20000C	12	30	61180-0000-0500	8	20	63755-J1R5-010007	1	35	7221A-I853-0000	12	19	86400-J1R5-000001	10	36
51117-0000-61000C	11	29	613140120ZGT0000X	6	20	69110-J862-000065	1	19	7221M-I853-000001	6	19	86407-J1R5-000001	3	36
51124-0000-02000C	16	29	613140400ZPT0000X	5	46	69120-J862-000065	3	19	72301-I853-C00002	9	19	86500-J1R5-000001	6	41
51124-0000-04000C	16	30	621430710ZGR0000X	9	20	71101-I853-C10065	1	25	72310-I853-0000	1	28	86600-J1R5-000001	7	41

ÍNDICE DE REFERENCIAS

PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.	PARTE N°	FIG. No.	PAG. No.
87100-I853-C26012	1	36	9A113-1060-01071X	3	37	B0009701080000K1X	11	24	B061870108000061X	5	44	B1667402100070S1X	1	33
87101-J1R5-000001	7	36	9A113-1060-01271X	11	27	B0084500042016X1X	7	35	B061870210000061X	4	16	B1667402100075S1X	2	33
87200-J1R5-000001	10	20	9A113-1060-01671X	13	16	B0088200060018T1X	13	23	B061870210000061X	5	17	B166740210011071X	1	17
87330-L0M1-0100	7	29	9A113-1060-01671X	5	35	B0088200060032T1X	14	24	B061870210000061X	3	33	CAL100L001-1	1	47
90/90-19-MR-923-TT	1	29	9A113-1060-01671X	5	38	B008940158000000S	10	34	B061870212000061X	6	29	CAL125C002-1	2	47
91113-6100-03571X	3	16	9A113-1060-01671X	7	44	B057830006002071X	2	23	B061870214000061X	5	30	CAL125C002-2	2	47
91118-6100-03771X	7	34	9A113-1060-02071X	6	16	B057830006003571X	7	23	B166740106001071X	3	32	CAL125C003-1	3	47
91206-1060-02001X	4	18	9A113-1060-02071X	3	39	B057830008002571X	3	23	B166740106001271X	12	28	CAL125C003-2	3	47
91218-1060-025T0U	8	37	9A113-1060-03071X	4	37	B057890008002071X	7	17	B166740106001271X	6	33	CAL125C004-1	4	47
91218-1060-025T0U	4	40	9A113-1060-03571X	5	37	B057890008002571X	9	22	B166740106001271X	4	34	CAL125C004-2	4	47
91301-0060-25021X	7	33	B000700108003070C	6	26	B057890008002571X	9	28	B166740106001271X	13	35	CAL125C005-1	5	47
91301-0170-23021X	9	23	B000910002001801X	15	23	B057890008002571X	3	44	B166740106001271X	13	43	CAL125C005-2	5	47
91302-0060-20091X	11	17	B000910002001801X	13	24	B057890008003071X	1	20	B166740106001271X	6	45	CAL125C006-1	6	47
91302-0060-20091X	11	36	B000910002002001X	16	24	B057890008003071X	5	24	B166740106001671X	2	18	CAL125C006-2	6	47
91302-0060-25061X	3	21	B000910003002501X	10	23	B057890008003571X	8	28	B166740106001671X	2	21	CAL125C007-1	7	47
91302-0065-20121X	13	36	B0009601060000K1X	1	16	B0578900080045T1X	11	22	B166740106001671X	7	40	CAL125C007-2	7	47
91302-0080-32111X	12	22	B0009601060000K1X	3	18	B0578900080045T1X	2	44	B166740106001671X	11	43	CAL125C008-1	10	47
91302-0140-25040U	12	33	B0009601060000K1X	5	34	B0578900080075T1X	14	17	B166740106001671X	2	45	CAL125C008-2	10	47
91302-9060-15041X	9	37	B0009601060000K1X	6	35	B0578900080090T1X	2	17	B166740106002071X	1	15	CAL125C009-1	11	47
91302-9060-15041X	7	38	B0009601060000K1X	4	36	B061700006000061X	8	23	B166740106002071X	10	17	CAL125C009-2	11	47
91302-9060-18081X	8	16	B0009601060000K1X	8	40	B061710014000061X	9	33	B166740106002071X	14	19	CAL125C010-1	13	47
91302-9060-18081X	4	39	B0009601060000K1X	4	41	B061770106000061X	4	15	B166740106002071X	11	20	CAL125C010-2	13	47
91302-9060-20161X	10	37	B0009601060000K1X	6	44	B061770106000061X	7	31	B166740106002071X	6	34	CAL125C011-1	14	47
91302-9080-25191X	2	20	B0009601060000K1X	3	45	B061770106000061X	5	36	B166740106002071X	6	36	CAL125C011-2	14	47
91304-0085-12271X	16	22	B0009601080000K1X	9	17	B061770106000061X	5	40	B166740106002071X	6	40	CAL125C012-1	8	47
91311-G124-0000	14	16	B0009601080000K1X	13	22	B061770106000061X	5	41	B166740106002571X	2	46	CAL125C012-2	8	47
91311-G124-0000	9	35	B0009601080000K1X	4	44	B061770106000061X	3	46	B166740106003571X	13	27	CAL125C013-1	9	47
91311-M288-0200	12	27	B0009701060000K1X	14	23	B061770210000061X	8	34	B166740108001671X	2	32	CAL125C013-2	9	47
91311-M288-0200	7	37	B0009701060000K1X	15	24	B061870106000061X	16	19	B166740108003071X	1	22	MTX7D-BS-GEL-PRO	14	43
92102-000063012RS	9	29	B0009701060000K1X	6	31	B061870108000061X	6	17	B166740108003570G	17	25			
92102-000063022RS	11	30	B0009701080000K0G	2	25	B061870108000061X	14	22	B166740108004070G	16	25			

FICHA TÉCNICA VICTORY MRX 125



CARACTERÍSTICA	UNIDAD
Motor	4 Tiempos, monocilíndrico, Refrigerado por Aire
Diámetro x Carrera	52.4 x 57.8 mm.
Índice de Compresión	9.5:1
Potencia Máxima	9.65 HP @ 7500 RPM
Torque Máximo	9.2 NM @ 6000 RPM
Bujía	NGK - CPR8EA
Arranque	Eléctrico y pedal
Transmisión	Mecánica, 5 Velocidades
Sistema de Lubricación	Forzada, Bomba Trocoidal
Sistema de Alimentación	Carburador
Refrigeración	Aire
FRENOS	
Freno Delantero	Disco de 267 mm.
Freno Trasero	Campana de 130 mm.
SUSPENSION	
Suspensión Delantera	Horquilla Telescópica
Suspensión Trasera	Brazo Oscilante con Mono Amortiguador
CAPACIDAD DEL TANQUE	
Lleno	2.9 Gal. (11 Litros)
Combustible	Gasolina
LLANTAS	
Llanta Delantera	90/90-19
Llanta Trasera	110/90-17
Rines	Radios
SISTEMA ELECTRICO	
Sistema de Ignición	C.D.I.
Bombillo Farola	12V - 35/35W
Luz de Stop	12V - 21/5W
Luces Direccionales	LED
Pito	12V
Batería	12V - 7AH
DIMENSIONES	
Largo x Ancho x Alto	2060 mm x 830 mm x 1160 mm
Distancia Entre Ejes	1340 mm.
Altura al Piso	240 mm.
Peso en Seco	113 Kg.

NUEVO*
MOBIL SUPER™
4T ULTRA AUTECO®



**Identifícalo
por la tapa Roja**

- Menor consumo de aceite
- Mayor vida útil del motor

* Nueva presentación etiqueta y nuevo empaque.

Mobil™

auteco®